



FlapLock FL01 Fitting Instructions

1. Remove protective film from the adhesive pads
2. Present the Flaplock to the inside face of the door making sure that the aperture in the door aligns with the aperture in the Flaplock and the solid door surface is clean and dry.
3. Press the adhesive pads firmly against the door. The Flaplock will now hold in position.

The FlapLock is now firmly fixed to a shear strength of 30.6 kilos. For additional strength where necessary please proceed to items 4-9.

4. Remove the two screws from the top of the Flaplock cover plate.
5. Remove the Flaplock cover plate completely and put to one side.
6. The Flaplock backplate has a number (6) of fixing holes to left and right of the mail aperture. Choose any two for screw fixing.
7. Drill a pilot hole into the door to a depth of approx. 20mm. through the chosen fixing holes either side of the main aperture. (Use drill bit appropriate for your door construction and to accept the self tapping screws provided).
8. With the screws supplied (4 S.T. 25mm) screw fix into the pilot holes already prepared.
9. Re-present the Flaplock cover plate complete with its flap and re-fit the two screws on the top.

The FlapLock is now secured to maximum strength.