



## FlapGUARD - Instructions for Fire Rated Doors

1. Ensure that the inside surface of the door is clean, dry and free of grease.
2. Carefully remove the protective film from the Ultra High Bond (UHB) adhesive pads.
3. Press FlapGUARD firmly against the door, FlapGUARD will then be securely fixed by the UHB pads, the adhesion reaches maximum strength after approximately 72 hours.

This method of securing FlapGUARD is suitable for Fire Rated Doors (FD30/FD60 etc.) Should an additional level of strength be required and it is a NFD (Non Fire Rated) door, please follow the instructions for Level Two below.

## FlapGUARD - Instructions for None Fire Doors Only

After FlapGUARD has been fitted in the usual way with the UHB pads...

4. remove the 2 screws from each end of the FlapGUARD cover plate.
5. Remove the FlapGUARD cover plate and set to one side with the screws.
6. Drill pilot holes approximately 20mm deep through the 4 fixing holes on the inside of the FlapGUARD mounting plate.
7. Using the screws supplied fix the FlapGUARD mounting plate securely to the door.
8. Replace the FlapGUARD cover plate and replace the original screws in each end. FlapGUARD mounted in this way is Sold Secure Domestic Bronze Accredited

**Note:** The door must be at least 38mm thick. Extreme care must be taken not to drill completely through the door. FlapGUARD & Solon Security cannot be held liable for damage caused by the filter during installation.

For more information on our product range visit: [solonsecurity.co.uk](http://solonsecurity.co.uk)  
 Get in touch with our sales team today:  
[sales@solonsecurity.co.uk](mailto:sales@solonsecurity.co.uk) / 01352 762266

