

BATTERY POWERED SIMULATED TV

Simple Device To Deter Burglars

Product Code: EL00214

Introduction

The Essentials Battery Powered Simulated TV is a simple but effective method of deterring burglars and opportunist thieves.

When switched on the unit's 6 coloured LEDs flash in a random sequence, simulating the light given off by a television. When used after dusk and installed in a tactical location within a property, anyone outdoors would assume someone is home watching TV.

The unit is activated by simply flicking setting the rear switch to On or Off, giving the user full choice over when it is in use. Fully battery powered with no wires or plugs, the unit is fully portable and can be moved around a property as desired.

Locating your Essentials Battery Powered Simulated TV

Ground Floor If the Essentials Battery Powered Simulated TV is used on the ground floor, for best results place the unit near the window. Make sure that shades, curtains or blinds are closed. Ensure the unit cannot be seen from the window.

Upper Floors If the Essentials Battery Powered Simulated TV is used on an upper floor, there is no need to plug it in it near the window.

Operation

When the switch on the rear of the unit is set to On, the device will activate immediately. When the switch on the rear of the unit is set to Off, the device will stop immediately.

Installing and Replacing Batteries

The Essentials Battery Powered Simulated TV does not come with any batteries included.

The unit operates off 3 x AAA batteries. Simply remove the rear cover and install the batteries, noting the correct polarity. Replace the cover and your unit is ready to use.

It is recommended to test your batteries regularly by switching the unit On. If the LED lights seem dimmer than usual, or fail to come on at all, then change your batteries. To do this, follow the steps above.

Solon Security

Unit 40
Manor Industrial Estate
Flint, Flintshire
CH6 5UY

solonsecurity.co.uk

Industry leaders in quality



FS 565100 EMS 655345

