

# SQUEEZE ALARM

Squeeze activated alarm with torch

Product Code: AL00038

## Introduction

The Squeeze Alarm is a simple but effective personal protection device with a 120dBs siren plus handy push-button torch feature.

## Operation

Before operating the Squeeze Alarm for the first time please remove the plastic tab covering the batteries by gently pulling it.

1. To operate the alarm, simply press both sides of the unit at the same time. You do not have to continue to press the sides; once activated, the alarm will sound until turned off.
2. To turn the alarm off, press the button on the front of the unit.
3. To operate the torch, press the button on the front of the unit.

The alarm has a metal clip that can be attached to clothing or utilised with a key ring (not supplied), for enhanced portability.

## Battery installation/replacement

It is recommended that the alarm is tested regularly. If the alarm or light appears weak, the batteries should be replaced. To replace the batteries, remove the four screws from the back cover and replace the batteries noting the correct polarity. The unit operates by 3 x LR44 (or equivalent) button batteries.

## WARNING

The high output siren fitted to this quality personal alarm may cause ear damage if used at close range for a prolonged period of time. Keep away from children and pets ears. This product is designed for use as a deterrent; it does not guarantee protection or personal safety.