

REMOTE CONTROL SOCKET

Remote activation for electrical appliances.

Product Code: OT01512/13

Introduction

The Defender Remote Control Socket set allows users to activate electronic appliances such as lamps or televisions at the click of a button. Ideal for use with plugs that are in hard to reach places. The battery powered remote has a range of 20 metres to each socket and is easily paired within seconds.

Pairing

Important: First remove the plastic battery tab from your remote by pulling it out firmly.

Plug your socket into the desired wall-socket and turn the mains power on.

The red light on your plug-in socket should flash steadily. If it does not flash, press and hold the ON/OFF button on the socket for 5 seconds until it flashes.

Decide which number on your remote control you wish to apply this plug-in socket to.

Press and hold this number's ON button on the remote for 3 seconds, whilst within 20 metres of the socket.

The socket's red light should stop flashing, confirming successful pairing.

Insert your appliance's plug into the plug-in socket.

Repeat this step for any other sockets that you have. Maximum 4 sockets per remote control.

Operation

Using your remote control, press the relevant number's ON or OFF button to activate or deactivate your appliance.

You can also use the 'ALL' ON/OFF button to activate or deactivate all paired sockets and their related appliances.

The sockets and their appliances can also be operated manually by short pressing the ON/OFF switch located on the socket.

Resetting

If you wish to un-pair or reset any sockets, press and hold the socket's ON/OFF button for 5 seconds until the red light starts flashing. Your socket is now unpaired. To re-pair, follow the steps in the Pairing section above.

You can also press and hold the 'ALL' OFF switch on your remote control for 5 seconds to un-pair all linked sockets.

NOTE: If mains power to the plug-in socket is lost, all preset pairings will be reset. To re-pair, follow the steps in the Pairing section above.

Remote Control Batteries

Your remote comes with 2 x LR44 batteries installed. Remove the plastic battery tab to use the remote. If low battery occurs, unscrew the battery compartment to replace, rescrewing when done.

Spec:

Voltage: 240V-/50Hz

Max Power: 3100W

Remote frequency: 433MHz

Remote range: 20 metres

Contact us:

solon-group.com