


## How to reset your combination



### Step 1

Set the lock by aligning the combination number to the factory preset combination 0-0-0-0 with the Guide Line. (Fig. 1)

### Step 2

Rotate the Reset Button 150° counterclockwise to the reset condition. (Fig. 2)

### Step 3

Set your desired combination. (Fig. 3)

### Step 4

Rotate the Reset Button 150° clockwise to its original position. Verify your new combination before using the lock. Then, your lock is ready to use. (Fig. 4)

