


HD Video Doorbell



Quick Start Guide

BOX CONTENTS

- 1 x HD Video Doorbell
- 1 x Plug-in chime
- 1 x Flat mounting bracket
- 1 x Angled mounting bracket (*optional, for angled walls*)
- 1 x 3M adhesive mounting sticker
- 1 x 32GB SD card (*already inserted*)
- 1 x Warning sticker
- 1 x USB charging cable
- 1 x Small allen key
- 3 x Security screws; 1 use + 2 spares (*matching head to allen key*)
- 2 x Mounting screws + wall plugs (*largest*)
- 2 x Additional mounting screws (*smallest, angled bracket only*)
- 2 x Hardwiring connection wires (*optional, professional only*)
- 2 x Conductor screws (*optional, for hardwiring only*)

IMPORTANT INFORMATION – PLEASE READ

The following quick start guide provides steps for regular everyday installation, setup and usage of the HD Video Doorbell.

More advanced product information, app features, troubleshooting and FAQs can be found by scanning the QR codes opposite, or by visiting the FAQ section of the app.

A working 2.4Ghz WiFi connection is required to set up this device. ***This device will not connect with 5.0Ghz networks.***

It is recommended to set up your doorbell with the app and chime before physical installation;

- Use the live playback on your phone to pick an installation spot with the best view.
- Pair the plug-in chime with the doorbell held close by for a simple pairing.



Product FAQs & Info



Tuya Smart Help Centre



DOORBELL GUIDE



Waterproof Cover



TF Card

Micro USB
5V/2A

(remove mounting bracket to access)


SETUP & APP PAIRING

1. Download the Tuya Smart app on your phone.
Search Tuya Smart on your app/play store, or scan below.



Note: the Tuya Smart app has various sophisticated features like home automation, cloud storage Alexa/Google pairing etc. These features are not required to use the doorbell day-to-day and are not covered in this quick start guide. To learn more about those features, consult the FAQ within the app.


2. 'Sign Up' to create an account with your email. Complete the verification steps and set your password.
3. On the Home screen, choose 'Add Device' or '+' in top right.
4. Choose 'Add Manually', then 'Camera and Lock', then select 'Smart Doorbell'



5. Press and hold the ON button on your doorbell until the light flashes blue. The light should then slowly flash red.


6. Tick the box on the app and press Next.

7. Enter your WiFi details carefully. 2.4Ghz only. Press Next.



8. Hold the QR code that appears up to the doorbell's camera until you hear a tone. Press 'I heard a prompt'.

9. Pairing will complete when you hear a tone. Name your doorbell and press done. **You are now setup with the app.**



PAIRING WITH CHIME

As well as activating your phone when pressed, the doorbell also comes with a plug-in chime for normal household alerts. The Melody button is on the left and Volume button on the right.

The doorbell and chime are connected via 443Hz frequency (not WiFi). After pairing, it is suggested to have them installed within 20ft of each other for best performance. Very thick walls may reduce the signal strength. If so, move them closer.

During the actual pairing process, it is recommended to have the doorbell next to the chime for ease.

1. Plug the chime into an active socket. It will ding and flash.
2. Press the Volume button repeatedly to choose your desired volume. There are 5 options including silent (flash only).
3. You can stick with the default tone (skip to step 4), or press the Melody button repeatedly to hear all 52 options.
4. On the tone you want, press and hold the Volume button until the light stays blue.
5. Within 5 seconds, press the ring button on the doorbell.

The units should now be paired.

You can adjust the volume at any time without re-pairing.

Any change in melody will not take effect unless you re-pair.

If you move the location of the chime, test the connection in the new location and re-pair if necessary.

CHARGING THE DOORBELL


The doorbell contains 2 x long life 18650 lithium-ion batteries that, on a full charge, can provide up to 6 months continuous usage, subject to the amount of activations and connections.

The batteries are fully sealed within the unit and controlled using the On/Off switch – **DO NOT ATTEMPT TO ACCESS THE BATTERIES, IT COULD CAUSE SERIOUS HARM.**

The doorbell should not require charging before first use and the battery life is displayed clearly within the app's live view.

When you do require charging simply remove the doorbell from its bracket (removing the security screw).

Utilise the micro USB cable provided and connect it to doorbell's side port and a suitable 5V/2A power supply.



A full charge should take approximately 4 hours. The light will flash blue during charging and you can use your app to check the charge percentage at your leisure.


INSTALLING THE DOORBELL

You can mount your doorbell with either the adhesive sticker or the screws supplied. Install at a height to suit your needs. Always fix the security screw in the base after installation.


Do not install on surfaces containing metal – this can affect the camera's wireless signal.

Adhesive Sticker – optional for smooth surfaces e.g. UPVC
Note that the sticker may leave some residue if removed.

1. Peel off one side of the double-sided 3M sticker and affix it to the rear of the waterproof bracket (NOT the doorbell) so that all holes match up.
2. Peel off the remaining side and press against the wall in your desired location. Maintain pressure until firm.
3. Insert doorbell into the bracket and affix security screw.



Screws – best suited for brick walls, wood and concrete.




1. Line up the bracket at your desired location on the wall and mark your drill points within the top and bottom holes.

2. Hold the bracket steady and place your first long screw in line with the bottom hole.

3. Using a drill and suitable drill bit, tighten the bottom screw

into the surface until secure. Repeat for the top hole.

4. Insert doorbell into the bracket and affix security screw.



If using the angled bracket with either method, first fix it to the flat bracket using the smallest screws provided.

Place the flat bracket on top of the angled bracket until all holes match up and fix the screws within the small round holes. Then follow the above steps.

This doorbell can be hardwired to an existing mains wired doorbell using the wires and screws provided.

This should be done by a professional electrician only and we do not provide formal installation guidance for this. See our online FAQ for further info.

USING THE APP

Home: View and access all devices you have added.

Scene: If using automation etc. (not required); see Tuya Help.



Smart: If using automation etc. (not required); see Tuya Help.

Me: Account info and message centre for doorbell alerts.

Live View / Quick Toolbar / Control Panel

Opening the doorbell presents the live view, plus a quick toolbar and control panel.

Here you can view and capture footage, plus change settings.



Quick Toolbar Icons:

- Square: Rotates view into fullscreen mode.
- Camera: Takes a screenshot, saving to your Gallery.
- Phone: Allows a two-way conversation.
- Vid Camera: Records the current view to your Gallery.
- Up Arrow: Expands the toolbar into the full Control Panel.

Control Panel Icons:

- Playback: A timeline of your captured footage.
- Gallery: View screenshots and footage you have saved.
- Theme: Edit your app background appearance.
- Volume: Change loudness of your external doorbell sound.
- PIR: Edit your motion capture sensitivity.
- Siren: Access and activate your external doorbell alarm.
- Edit: Manage button layout.

Within the Control Panel view you can also toggle to a quick view of the Messages page (which shows visitor/motion notifications) or the Cloud section for value-added purchases (third-party controlled and not required for day-to-day function).

Notifications and Visitors

The system is preset to send notifications to your phone when either the doorbell is rang or motion is detected. Clicking on these shows a preview in the app's message centre; click view to access the live view/control panel. If it is in real-time, you can communicate with the visitor. If not, see next section.

You can also access these alerts in the Message Centre by clicking the Me section on the home page.



You can customise the area of motion detection e.g. limiting to your property only. See the 'Recommended Settings' section. Here you can also schedule certain periods for motion detection to be on/off.

Viewing Past Footage

In Control Panel, select Playback. Here you can navigate to different dates and scroll the timeline to view captured footage, which is shown as blue blocks. The view will default to the most recent day of captured footage, you can select older dates by pressing the calendar icon.

Use two fingers to zoom in/out to navigate the playback bars easily. Swiping right auto-plays the next footage, or you can manually scroll left and right to select certain blocks. You can also screenshot/record footage to the app album here using the appropriate icons.



Sharing Footage

Any screenshots and recordings are saved to the Gallery in the control panel. From here you can select and share the clips in the multiple ways displayed.

Sharing the Doorbell

In Settings, select Share Device and Add Sharing. You can send a direct invitation link in the multiple ways displayed, but the receiver must download the app and create a Tuya Smart account before they can accept.

The receiver can then simply click the link to open the app and 'accept' the viewing. Shared users can view footage but cannot edit settings. There is no limit to how many shares you can action. You can remove shared users at any time by going to the same section.

Resetting the Doorbell

Press and hold the reset button on the rear until you hear a tone. The doorbell will re-enter pairing mode. **Any footage within the app will be lost**, so consider backing up/saving to your phone library if required. SD card footage will remain.

Removing the Doorbell from the App

In Settings, scroll to the very bottom and select Remove Device. **This clears all footage and settings**. SD card footage will remain

Recommended Settings

You can access the doorbell settings by selecting the top right icon in the live view. The below are recommendations only, but in most cases will ensure good overall performance:

1. Edit the PIR sensitivity level to suit your needs; Low/Medium is usually suitable for most homes. Test what works for you.
2. Turn human body filtering ON in Detection Alarm Settings to only detect humans; this minimises false alerts from animals, vehicles etc., which reduces notifications and battery usage.
3. Turn activity area ON in Detection Alarm Settings to enable you to adjust the area your PIR detection is active via the surveillance area setting section. The area outside of your red grid will not be detected.
4. Set a low battery level in Power Management Settings. This will send a notification reminding you to charge.
5. Turn Offline Notification ON. This sends a notification if the doorbell loses signal for more than 30 minutes.

Reminder – purchasing VAS/Cloud Services is not required for this system. Doing so is at your own discretion. These services are ran independently by Tuya Smart as a third-party.

Reminder – home management, tap to run automation and Alexa/Google features are for advanced users only and are not required to use this device day-to-day. Users who want to use these features should consult the Tuya Help page or the FAQ & Feedback section within the app.

Solon Security
Unit 40 Manor Industrial Estate
Flint, Flintshire
CH6 5UY

solon-group.com