

WRIST ALARM

Stylish Wrist Alarm

Product Code: AL00009

Introduction

The unique watch style design is unobtrusive to wear making it great for those that find clip on or key ring alarms unsuitable. The Wrist Alarm has a powerful 130dBs siren to shock attackers. The alarm has a highly durable 'one size fits all' Velcro strap which is easy to fit.

Operation of the alarm


1. To operate the alarm, simply push the button on the face of the alarm.
2. To stop the alarm sounding, push the button on the underside of the alarm.

Note:

Before using the Wrist Alarm for the first time please remove the plastic tab covering the batteries by gently pulling it.

Battery replacement

It is recommended that the alarm is tested regularly. If the alarm sounds weak, the batteries should be replaced. To replace the batteries, tear the Velcro apart (see image below) and remove the two spring loaded pins. To remove the pins, pull the pin between the threads and the hole where the pin fits. The pin will spring out. This gives you access to the back cover. Remove the four screws from the back cover and replace the batteries noting the correct polarity. The unit operates by 2 x LR44 (or equivalent) button batteries. Then put the screws and the pins back in place.



WARNING

The high output siren fitted to this quality personal alarm may cause ear damage if used at close range for a prolonged period of time.

Keep away from children and pets ears.

This product is designed for use as a deterrent; it does not guarantee protection or personal safety.

CAUTION

- When testing the alarm, make sure you hold it at least at arm's length away from your ear.
- The power source or propellant has a finite / limited life.
- DO NOT MODIFY THE ALARM.
- The alarm should be kept out of reach and audible range of children and pets.

Note:

Performance may be adversely affected following prolonged exposure to extreme temperatures.

Personal Safety Alarm Guidance

It is advised that use of an audible personal alarm should not be relied on as the sole means of preventing an attack and should be used in conjunction with other precautionary measures. Please note the following advice:

General use

- Always have the alarm close to hand and ready for use.
- Plan your route / journey in advance.
- Tell someone where you are going and what time you will be back.
- Walk with confidence.
- Be alert.

When in your car

- Always have the alarm close to hand and ready for use.
- Always park in well lit areas.
- Have the keys ready as you approach your car.
- If another vehicle (including the police) is signalling you to stop, do not pull over in an isolated spot, wait until you reach a safe area.
- Be alert at all times.

Before you use your alarm

- Be sure you know how to activate and de-activate the alarm.
- Make regular checks on power and at the first indication of a weak sound, replace the battery.
- Practice appropriate means of carrying the alarm ready for use.

Remember

Personal safety alarms are designed for use by individuals who are under threat from attack and should be used with care and responsibility. It is intended to shock and disorientate an attacker to provide a distraction so that the user can make an escape.

It is not intended to be used as a distress signal for attracting help and attention. However the noise may induce fear of intervention and detection of others so this is an opportune secondary function.

DON'T FORGET AN AUDIBLE PERSONAL ALARM SHOULD NOT BE EXPECTED TO PROVIDE A COMPLETE SAFEGUARD AGAINST ASSAULT AND USERS SHOULD ALWAYS TAKE SUITABLE PRECAUTIONS TO REDUCE THE RISK OF ATTACK.

Contact us:
solon-group.com

